Download PunchSensor from this link: PunchSensor

1. Run setup.exe. This will install the drivers and the software and also create a PunchSensor icon (Load VUE Icon)on the desktop.
2. Run PunchSensor by double-clicking on this icon.

The software will try to install the required drivers as part of the installation. However, in some Windows installations, this may not work. If this happens please download and install drivers by clicking on the link below:
http://www.ftdichip.com/Drivers/CDM/CDM20828_Setup.exe