

Other

<input type="checkbox"/> Sensor	Interface	Software	Calibration
<input type="checkbox"/> Type	DI-100U	LV-100	Compression
<input type="checkbox"/> Capacity	DI-1000U	LV-1000	Tension
	DI-400U	SV-1000	Universal
	AI-1000	CV-1000	

### What is Included



*Thank You!*

*Dir Harish    Connie  
Uma    Raka    Viet  
Soundar    Mantej*

**PLEASE READ FIRST...**

### Software:

Install the Software and Drivers from the USB Drive Provided. Then, Set Latency Timer to 1ms.

your PC.

### Power Supply:

No Power Supply Needed for USB Kits. The System is powered by USB port of

clients are Burned into and Stored in the Interface

Your Load Cell and Interface must be used as a pair. The Calibration Coeffi-

We recommend that you Recalibrate your sensor once a year.

Do Not Recalibrate (Unless Necessary).

with your kit.

This kit is Pre-Calibrated and Ready to Use. Calibration Certificate is included

### Calibration:

### Please Note:

## Help

- [loadstarsensors.com/specsheets.html](http://loadstarsensors.com/specsheets.html)
- [loadstarsensors.com/sensors.html](http://loadstarsensors.com/sensors.html)
- [loadstarsensors.com/interface.html](http://loadstarsensors.com/interface.html)
- [loadstarsensors.com/software.html](http://loadstarsensors.com/software.html)
- [support@loadstarsensors.com](mailto:support@loadstarsensors.com)

## Warranty

90 Day Limited Manufacturer's Warranty  
Extended Warranty Available

## Tech Support

90 Day Remote Support within 1 Business Day  
Extended Tech Support Available

## Use at Your Own Risk

Loadstar Sensors is not liable for any damages resulting from using these products.