

Please Note:

We have included a spare external battery pack for your DI-1000ZP. In case the internal battery in the DI-1000ZP gets discharged or poses an issue, please connect the external battery pack to the DI-1000ZP unit as shown.



Insert the battery cable here

Make sure that the On/Off button is in the On position.